

Philips
Coffee spout

New Generation

Black

CRP705



Guarantees that your coffee flows into the cup(s)

Go to the Specifications Tab to check your matching product

The coffee spout, a small part of your SENSEO® coffee machine, can easily get lost. Have you lost your current one? You can order a new one here!

Ease of using Philips spare parts

- Renew your product with original Philips parts

PHILIPS
sense and simplicity

Specifications

Replaceable part

- Fits product types: HD7825/10, HD7825/11, HD7825/20, HD7825/21, HD7825/30, HD7825/31, HD7825/40, HD7825/41, HD7825/50, HD7825/51, HD7825/60, HD7825/61, HD7825/

62, HD7825/70, HD7825/71, HD7825/80, HD7825/81, HD7827/50, HD7827/51, HD7827/52, HD7828/10, HD7828/11, HD7835/10, HD7835/11

Highlights

Easy replacement

From time to time your product needs a facelift, and with Philips consumer replacement parts to renew your product, it's never been so easy! All this with guaranteed Philips quality and 1:1 exchange.



Issue date 2013-01-10

Version: 2.0.1

© 2013 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

www.philips.com